



Setup guide

for



Integration

Features

- Settings directly in the transmitter
- Configuration of the unit
- No need for computer
- Everything quickly accessible

Requirements

- OpenTX 2.2 with Lua support
- Receiver with S.Port
- Integration cable for S.Port

1. WIRING

To enable the Integration, you have to only connect your receiver and unit according to the following scheme. Please note, that to make this possible, you will need special cable that is available in our eshop.

Longer lead of the cable – unit; the **SYS port**.

Shorter lead of the cable – receiver; the **S.Port**.

The integration cable is used for bi-directional data transmission between unit and receiver, respectively transmitter. This include telemetry data and possibility to configure all parameters of the unit, directly from your transmitter.

It is completely separated from basic receiver part that is transmitting the channel data. Thus your existing connection with receiver can be untouched. It can work with PWM, PPM and S-Bus connection types.

NOTE

For receiver that has a Molex connector for the S.Port (e.g. X4R, X4R-SB, XSR), please use provided connector and pins so that you can easily connect it to the servo connector.

NOTE

S.Port connection alone will not work – it is used only for configuration. Channel data must be transmitted by a conventional protocols such as PWM, PPM or S-Bus.



Example 1: connection scheme for the Integration part with X4R-SB receiver



Example 2: Optional adapter for X4R, X4R-SB, XSR receivers

2. INSTALLATION

Configuration of the unit is accessible through Lua scripts. These scripts are tailored by Spirit System to allow full integration with the unit. With this integration you can access all the menus and configure any parameter whenever you wish.

To make it work, you have to download and copy the scripts from our web: <http://www.spirit-system.com/dl/opentx/Spirit.zip> – Optimized for Taranis X9D/X9D+/X9E:

Then unzip the file and copy the „Spirit“ directory to SD Card of your transmitter.

3. HOW TO OPEN THE MENU

You can access the integration menu whenever you want to configure the unit.

When it is opened, it behaves similarly as when you start the PC software.

This means that for example Bank Switching will be performed in the menu, not with assigned switch.

When script is closed, everything returns to the flight regime.

WARNING

Do not configure the unit during a flight!

To access the menu, press the buttons in the following way:

1. Press the *MENU* button for 1 second.
2. Click the *PAGE* button.
3. By clicking *+* and *-* buttons move to the „*Spirit*“ directory.
4. Click the *ENT* button.
5. Start the *basic.lua* or *special.lua* script by clicking the *ENT* button.

